



1. Product name

Fibre Optics Torch with 100 cm strands


2. Product code

21937112

3. Colour

The fibre optics torch has 12 positions.

- 1- White
- 2- Red
- 3- Green
- 4- Dark blue
- 5- Light red
- 6- Aqua blue
- 7- Violet
- 8- Orange
- 9- Light blue
- 10- Rose
- 11- Flashing all colours successively
- 12- Overflowing all colours successively



4. Short description

The fiber optic flashlight has different colours and positions. The wireless flashlight can be used anywhere! The weight is light, which makes the product suitable for everyone and easily transportable.

5. Sense Stimulations

Sight, Touch

6. Technical information

Dimensions: 1 metre fiber optic strands, 15 cm flashlight

7. Cleaning

You can clean the product with a damp cloth. Clean gently through the fiber optic strands without pulling.

8. Installation

Open the packaging of the handle. The packaging contains: batteries, an Allen key, and of course the handle.

- 1) Unscrew the small ring at the back of the handle (where the rope is attached)



In the handle is a holder for batteries. Take this holder out of the handle to insert the batteries.



Once the batteries are put in the holder, put the holder back in the flashlight and close the bottom again.

2) Now you can attach the fiber optic strands to the handle. Use the Allen key with the two small screws and insert the strands of optical fibers into the handle and then attach and screw the two screws.



3) You can now activate the flashlight by pressing the black button at the end of the handle (near the cord). Then you can press the small black button on the side of the handle to change mode. See above at 3) colour, the existing modes.



Press the small button on the side, for a few seconds, the flashlight goes into flashing mode.

For more information, please visit our [website www.nenko.com](http://www.nenko.com).

