



## 1. Product name

Nenke Sensory Wagon Sense System

## 2. Product code

21981010

## 3. Short description

This Sense System Snoezel Trolley is delivered in a wooden transport crate for safety and service reasons.

= We recommend keeping this wooden crate for future service purposes =

1. Open the transport crate with a Phillips screwdriver.
2. Release the brakes on the front wheels and roll the trolley out of the crate.
3. Hang the fibre optics next to the trolley.
4. The key to open the front and back of the trolley is located on top.
5. Open the lower cabinet door at the front.
6. Take out the projector, LED spotlight and laser star and place them on the trolley.
7. Connect the tablet to the projector using the supplied HDMI cable.
8. The tablet will automatically connect to the Bluetooth controller (if it is plugged in and powered) when you open the Nenke app.
9. Connect the spotlight on top of the trolley to the thick black cable.
10. Take the 3-meter power cable. Plug one end into the outside socket (right side from the front) and the other into a wall outlet in the room.
11. Take the adapter (for the bubble unit) and plug it into the second outside connection under the fibre optics.
12. Open the back of the trolley using the key. A sliding module containing the bubble unit and mirror is located there. Pull it out gently using the handle.  
To slide it back in easily, push the back board slightly with your foot to tilt the unit, roll it fully in and let it drop back into place.
13. Place the sliding bubble module next to the trolley and lock the wheels.
14. Fill the bubble unit to 80 %, leaving room for bubbles.
15. Connect the other end of the small power cable to the bubble unit.
16. Open the front cabinet again. Inside is a control box with 6 red buttons. These are the power switches for all electronic components. The included diagram shows which button controls which device (left to right).  
Note: Always plug the main power cable of the trolley into the wall outlet first before switching on the red buttons!  
Button 1 Bubble unit  
Button 2 Fibre optics  
Button 3 Tablet + amplifier + mini projector  
Button 4 Star light projector  
Button 5 Spotlight  
Button 6 Aroma diffuser
17. The Snoezel Trolley is now ready for use!





#### **4. Sensory stimulation**

Touch, smell, hearing and sight

#### **5. Specifications**

Dimensions: 60 x 70 x 145 cm

Power supply: 220 V

#### **6. Included**

Everything as shown

- Disinfection tablets for bubble units – set of 5
- Extra oil cartridge for aroma diffuser
- Nenko LED light source for fibre optics
- Fragrance set with 4 oil blends
- Wall bracket for Sense screen
- Projector mount

For more information, you can visit our website [www.nenko.com](http://www.nenko.com)

