



1. Name of the product

Jelly Fish Tank Round mini

2. Product code

23643477

3. Short description

Fish tanks include neon jellyfish that whirl in the water as soon as the fish tank filled. Turn up the aquarium and not only the jellyfish swim around, but the aquarium also gives light. Colour depending on the stock

Round mini with 2 jelly fish.

4. Sensory stimulations

See

5. Specification

Size: 8.8x8.8x22cm (Approx)

Weight: 242g (Without Water) 940g (With Water) (Approx)

Material: ABS/PS

LED: 3 non – replaceable multi coloured LEDs

Bulb Rating: 0.06W

6. Contents

1 x Tank

A pack of Jellyfish

Required

700 ml of Distilled Water (Approx)

3 x 1.5V AA Batteries

7. Safety Warnings

- Before setting up the tank, ensure the product is not damaged. If any part of the product is damaged, do not attempt to assemble and use.
- Do not attempt to hardwire this product to the mains electrical supply. This product does not require to be connected to your mains electrical supply. It operates using 3 x 1.5V Batteries.
- This product contains non-replaceable LEDs. If any of the LEDs cease functioning, the whole unit must be disposed of according to your local council guidelines.
- This is not a toy. Contains small parts, potentially may cause choking hazard. Adult Supervision required.
- Remove all packaging before setup. Do not operate in packaging. Keep packaging away from children and pets.
- Handle with care.
- Keep away from heat sources or naked flame.
- Ensure the tank is placed on a steady, flat, and even surface.
- Ensure the tank is placed out of the reach of children and pets.





- **DO NOT** use live fish in this tank.
- Persons (including children) with reduced physical, sensory and mental capacities, or lack of experience and knowledge, **MUST BE** supervised by a competent person responsible for their safety.

8. Instructions

To Insert Batteries:

1. To insert batteries, remove the screw from battery cover and insert 3 x AA batteries.
2. Be sure to insert batteries with correct polarities and always follow the product and battery manufacturers' instructions.
3. Once batteries have been inserted, replace cover and always re-insert the screw in.

To add Water and Jellyfish

1. Remove the lid from the top of the tank.
2. Remove the rubber cap.
3. Fill the tube to the top with distilled water.
4. Turn on from on/off switch
5. Add 1-2 drops of dish washing detergent and wait for a minute.
6. Turn on the power at least 30 seconds before putting the jellyfish into the tube.
7. Carefully hold jellyfish by the tentacles to put into the tube. Fill inside of the body with water before letting go of them.
8. Try to avoid air bubbles in body of jellyfish. If necessary, use a straw or stick to help turn them to remove air bubbles.
9. Put rubber cap back on. Put the lid back on.
10. Please allow some time for the jellyfish to start swimming correctly around the tube, as it can take some time.
11. Change water occasionally when dirty.

Battery Warnings:

- Batteries should only be inserted or changed by a competent adult.
- Non-rechargeable batteries are not to be recharged.
- **DO NOT** mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- **NEVER** mix old batteries with new batteries (replace all batteries at the same time)
- Remove batteries from product before extended storage. Always remove old or exhausted batteries from the product.
- The supply terminals are not to be short circuited.
- Check that the contact surfaces are clean and bright before installing the batteries.
- **DO NOT** bury or burn batteries.
- Recycle used batteries responsibly. **DO NOT** dispose of in household waste.

For more information, you can visit our website www.nenko.com

