

1. Name of the product

Light Up Water Filled Glitter Ball

2. Product code

23749111

3. Short description

Relaxing desktop mood light, switch on colour phasing LEDs and shake to see the glitter swirl.




4. Sensory stimulations

See

5. Use

1. Remove the battery cover (FIG.AB)
2. Fit 3 pcs of size AAA 1.5V batteries to ensure the correct polarity (FIG.B.)
3. Covering up the battery as well as turning on the switch (FIG.C.)



- For indoor use only
- Do not drop this item, operate with care
- Keep battery box dry

For more information, you can visit our website www.nenko.com

