



1. Product name

Round sensory LED balance stones with liquid

2. Product code

25380477

3. Colour

As shown.

4. Short description

These stepping stones are filled with gel and feature a colourful liquid effect that immediately captures attention. When stepped on, the round sensory LED stepping stones with gel light up in multiple colours.

5. How to use

Shake the product: with each movement, the light will display a different colour – red, green, blue, yellow, orange, cyan, and purple. These seven colours alternate in a single cycle. If the product is not moved for two minutes, it will automatically switch to standby mode. When shaken again, the light will turn back on and display the colour that was visible before entering standby mode.

6. Safety

- Check regularly for damage. Do not use if damaged.
- Adult supervision required.
- Keep away from heat sources and direct sunlight.
- Remove the batteries if the toy will not be used for an extended period.
- This product contains non-replaceable LED lights.
- If an LED stops working, the entire product must be disposed of in accordance with local regulations.
- Maximum load: 70 kg.

7. Battery recommendations

1. Operates on 3 AA batteries (not included).
2. Batteries should only be replaced by an adult.
3. Do not mix old and new batteries.
4. Do not mix alkaline, standard, and rechargeable batteries.
5. Do not recharge non-rechargeable batteries.
6. Rechargeable batteries should only be charged under adult supervision.
7. Rechargeable batteries must be removed from the product before charging.
8. Always insert batteries with the correct polarity.
9. Remove exhausted batteries.
10. Never short-circuit the battery terminals.

For more information, you can visit our website www.nenko.com

