



### 1. Product name


Gel Floor Tile - Blue + Adaptor

### 2. Product code

26004477

### 3. Colour

Blue



### 4. Description

A great visual experience that encourages everyone to move. Each illuminated tile is filled with liquid gel. Step or move on the tile and make sure the liquid gel shifts in a particular pattern. The tile is resistant to jumping and strenuous use by children and adults, as well as the weight of a wheelchair. the tiles can also be incorporated into a customized pvc floor mat. These tiles have anti-slip on the underside.

### 5. Sensory stimulations

See and feel

### 6. Specifications

Dimensions: 50cm x 50cm x 1.6cm (approximately)

Maximum power consumption: 2.13 W

Bulbs: 21 non-replaceable LEDs

Input: AC 220V

Output: DC 12V 3A

### 7. Setting up

Please read these instructions carefully before starting and keep them for future reference. Check the contents of the packaging to ensure all necessary parts are included and that none are missing. Do not attempt to assemble the product if any parts are missing.

1. Carefully remove the product from the packaging, making sure the cable is not twisted or tangled.
2. As the tile does not require wiring, it comes with an adapter. Make sure a power socket is within reach without overstretching the cable.

#### Single tile

1. Connect the pin from the tile to the adapter.





### Multiple tiles

1. First, check each individual tile to ensure that every tile is working properly.
2. Then connect all the tiles together using the connectors. Connect one of the connectors to the adapter, plug it into the socket, and switch it on.

Note: The pin from the tile and the adapter can be connected in two ways, but only one of them will work. If you've connected everything correctly and the tile doesn't turn on, try unplugging the tile and adapter and reconnecting them the other way around.

## 8. Safety warnings

- Before installing the tile, ensure the product is not damaged. If any part of the product is damaged, do not attempt to assemble or use it.
- DO NOT attempt to connect this product to the mains electricity. This product does not require mains power; it operates using an adapter.
- This product contains non-replaceable LEDs. If one of the LEDs fails, the entire unit must be disposed of in accordance with your local council's guidelines.
- DO NOT use the product while it is still in its packaging.
- Use on a flat and level surface, away from water.
- Handle with care—if dropped or subject to impact, the product may become damaged.
- DO NOT place heavy loads on the tile.
- DO NOT jump on the tiles; the impact could damage the product.
- Recommended maximum weight: 200 kg.
- Keep away from heat sources or open flames.
- It is recommended not to wear shoes while using the product. Over time, this may cause wear and scratches on the surface of the tile.
- Ensure the cable is positioned in a way that eliminates tripping, entanglement, or strangulation hazards.





## 9. Maintenance

1. ALWAYS unplug the tile from the socket before cleaning or handling it.
2. The tile has an easy-to-clean surface. It can be cleaned with a damp sponge and/or mild disinfectants or cleaning agents.
3. Do not submerge in water.
4. In the event that the tile cracks and liquid leaks onto any surface, it can be cleaned.
5. If the liquid spills onto carpet, we recommend placing an absorbent cloth over the spill to soak up the excess. Then gently clean the area with warm water and washing-up liquid using a clean sponge. First, blot as much of the excess liquid as possible to dilute the dye, rinsing the sponge in a bowl of warm water after each blot. Then gently wipe the area with the sponge until the liquid fades. Depending on the amount of spillage, you may need to repeat this once or twice.

Note: The adapter is sold separately in the sole packaging. Please contact us for more information.

Keep the packaging and instructions, as they contain important information.

For more information, visit our website [www.nenko.com](http://www.nenko.com)

