



1. Product name

Nenko Audio System

2. Product code

42794101

3. Colour

As pictured.



4. Short description

The Nenko Audio system excels in simplicity, a special section that provides a platform or musical waterbed (**not included**) with sound and therefore vibration and which can be controlled in terms of volume and bass. Next to it is the part that controls the speakers in the room.

With a handy selection button you can select one of the optional sources such as CD / DVD / BD, Aux, but also built-in USB or paired Bluetooth device.

Weight 1.14 kg

Including speakers and USB stick, excluding CD/DVD/BD player.

Exclusive waterbed or musical plateau

5. Commissioning

5.1 Connecting hi-fi system and controller

See diagram below for the correct connection of the supplied Hi-Fi system.

In the following overview you will see the following products;

- Loudspeakerset (L+R)
- Amplifier
- Loudspeakerwires





To start with, connect the power supply plug (220v) of the amplifier. The connection for this is located on the back right, see image:



You need to connect the speaker wires colour to colour, so red to red and black to black. If a gray-black or wire is attached to the speakers, do gray on red and black on black. You also need to connect the speakers on the right side, so the left speaker on the left and the right speaker on the right. When used with a musical waterbed, it does not matter to the platform whether it is connected left or right.

If you have also ordered a CD / DVD player, it must also be connected to the amplifier. This must be done with the supplied red / white cable. You connect the cable according to the color, so red on red and white on white. The CD / DVD player must be connected to the CD / DVD input.

Volume control of musical waterbed and external speakers





By means of these buttons you can set the volume and bass of the speakers.

5.2 Temperature control

You can control the temperature with the control unit attached to the heating element. It is advised to keep it at about 28 degrees, however, it is not a problem to set it to maximum. Remember that the heating only serves to keep the water at a comfortable temperature (not cold), and not to heat people lying on the bed. The heating element must not be switched on with empty waterbed, this will cause your warranty to lapse in the event of a defect.

6. Maintenance

To prevent bacteria and algae formation in the waterbed, it is necessary that you add a bottle of conditioner to the waterbed every 6 months. To do this, open the zipper of the bisonyl cover and open the filling cap to add the bottle. Make sure you close it again. We advise you to repeat this every 6 months. You can order extra vials of conditioner from Nenko. You should also use the vinyl cleaner to clean the surface and between the sides of the purple waterbed bag every 3 months to ensure that it remains supple and does not leak. To do this, spray thinly on the bag and wipe with a soft slightly damp towel

7. Warranty

Waterbed (the number on the water bag and the note are required to obtain warranty): Heating element: 1 year warranty

The warranty expires if :

- the defects are the result of normal wear and tear, improper use or insufficient care;
- you cannot submit a purchase note and mattress number (present on the waterbed label);
- the prescribed maintenance has not been carried out;
- other than the prescribed maintenance materials have been used;
- installing, moving or moving the waterbed in the wrong way.

Amplifier specifications

Issue 1.0.

5 Source Options:

- **CD/DVD** – Phono Stereo Line Audio Input
- **Sensory Magic** – Phono Stereo Line Audio Input
- **Auxiliary** – Phono Stereo Line Audio Input
- **Portable** – 3.5mm Jack Stereo Input - MP3 – Build in USB
- **MP3** – Build in USB MP3
- Bluetooth –

2 Speaker Stereo Speaker Output

- Bass Pump/Speakers Stereo (Volume and Bass Control)





Freq. Response: 20Hz ~ 50KHz Rated Output Power:

110W x 2 @ 3 Ohms, +/-27V, THD=10% 86W x 2 @ 4 Ohms, +/- 27V, THD=10% 60W x 2 @ 6 Ohms, +/-27V, THD=10% 45W x 2 @ 8 Ohms, +/-27V, THD=10%

- **Satellite Speakers Stereo** (Volume, Treble, Bass and Balance Control)

Freq. Response: 20Hz ~ 50KHz Rated Output Power: 110W x 2 @ 3 Ohms, +/-27V, THD=10% 86W x 2 @ 4 Ohms, +/- 27V, THD=10% 60W x 2 @ 6 Ohms, +/-27V, THD=10% 45W x 2 @ 8 Ohms, +/-27V, THD=10%

Line Out - Phono Stereo Line Audio Output

Power Input - AC ~220V

For more information, you can visit our website www.nenko.com
